

Notice to users of ThermaCAM™ QuickView

Applicability	This notice applies to all versions of ThermaCAM™ QuickView up to and including version 1.3.
Background	When the user of ThermaCAM™ QuickView wants to delete an image in the image pane, he selects the image and either right-clicks Delete or presses the DELETE key.
Problem	If the user unintentionally selects a folder in the folder pane when deleting images in the image pane, and clicks Delete on the Edit menu or presses the DELETE key, the folder including all images will be deleted.
Reason	<p>The reason the user unintentionally may select a folder is due to the fact that, despite a folder has been selected, one or several images are also selected at the same time.</p> <p>This may suggest that only the selected images will be deleted.</p>
Critical consequences	<p>The user may accidently delete all images in a folder.</p> <p>Note that deleted folders and images are permanently deleted and can not be recovered from the Recycle Bin.</p>
Solution	The problem can be avoided if the user carefully reads all confirmation boxes

